



Tuscaloosa, Alabama U.S.A.

**Cleaning Instructions for Phifer SheerWeave Fabric Styles:**

1000, 2000, 2100, 2360, 2390, 2410, 2500, 2701, 2703, 2705, 2710, 3000, 4000ECO, 4100ECO, 4400ECO, 4500, 4600, 4550, 4650, 4700, 4800, 4901, 4903, 5000, 7100, Infinity<sub>2</sub>, BASIC

- With the exception of Infinity<sub>2</sub>, the above listed fabrics contain Microban antimicrobial protection.

The following cleaning practices will not affect the products' ability to resist the growth of microorganisms and are considered safe for routine cleaning.

- Clean with mild soap and water.
- Commercial and hospital grade cleaners/disinfectants may be used on the above referenced fabrics. Test in an inconspicuous area prior to use.
- Diluted bleach solution (10% dilution or less)
- Rinse thoroughly after cleaning.

**Cleaning Instructions for Phifer SheerWeave Fabric Styles:**

7000, 7300/7350, 7400/7450, 7500, 8000

Fabric should be regularly dusted/vacuumed as appropriate. If commercial spot cleaners are used, they must first be tested and allowed to dry on an inconspicuous area to ensure compatibility.

**Handling and Cleaning Instructions for Phifer SheerWeave Fabric Styles:**

Performance + 2390, Performance + 2410, Performance + 2500

The metallized coating is fragile and must be handled with care to avoid damage. Do not scrub. Do not use tape, solvents or abrasive cleaners which could damage the fabric coating.

Clean with a damp soft cloth using a mild detergent. Rinse with clean water and allow blind to dry in the down position.

**Paint solvents will damage the vinyl surface of the SheerWeave products and should not be used.**

If you need further assistance, please call 1-800-221-5497.